

<b>A</b>	
Air cleaner .....	6-23
Air conditioner & heater .....	3-22
Air conditioner filter .....	6-45
Axle oil .....	6-34
<b>B</b>	
Battery .....	6-42
Before starting engine .....	4-2
Belt tensioner .....	6-21
Boom kick out .....	4-21
Brake line filter .....	6-28
Bucket leveler .....	4-22
<b>C</b>	
Cab device .....	3-1
Charge air cooler .....	6-20
Cigar lighter .....	3-25
Cluster .....	3-2
Control device .....	3-19
Controller .....	3-27
Coolant level .....	6-17
<b>E</b>	
Engine control module(ECM) .....	3-27
Engine oil filter .....	6-15
Engine oil level .....	6-15
<b>F</b>	
Fan belt .....	6-21
Fault codes .....	3-11
Fuel filter .....	6-24
Fuel prefilter .....	6-24
Fuel water separator .....	6-24
Fuse box .....	3-27
<b>G</b>	
Gear selector lever .....	3-20
<b>H</b>	
Hydraulic oil changing .....	6-26
Hydraulic oil filling .....	6-26
Hydraulic oil level .....	6-26
Hydraulic safety lock lever .....	3-21
<b>L</b>	
LCD .....	3-8
Loading and unloading .....	5-6
Lubrication .....	6-37
<b>M</b>	
Machine control unit(MCU) .....	3-27
Maintenance chart .....	6-13
Maintenance check list .....	6-10
Major components .....	2-1
Master switch .....	3-26
<b>P</b>	
Pilot line filter .....	6-27
<b>R</b>	
Radiator and oil cooler .....	6-20
Recommended lubricants .....	6-9
Return filter .....	6-27
Radio and cassette .....	3-28
<b>S</b>	
Safety hints .....	1-1
Safety labels .....	0-5
Seat .....	3-26
Specifications .....	2-2
Storage .....	4-25
Switchs .....	3-14
<b>T</b>	
Tightening torque .....	6-5
Tire .....	6-29
Towing the machine .....	5-7
Transmission cold starting .....	4-6
Transmission control unit(TCU) .....	3-27
Transmission oil filter .....	6-32
Transmission oil level .....	6-32
Transportation .....	5-1
Travelling machine .....	4-9
Troubleshooting guide .....	7-1
<b>W</b>	
Warming up operation .....	4-7
Weight .....	2-5
Working method .....	4-14